

# Dura-Flex® Couplings

## Installation Instructions

P-7891-TBW



**⚠ WARNING** Lock out / tag out the power source before proceeding to avoid unexpected starts. Failure to observe these precautions could result in bodily injury.

**⚠ WARNING** Coupling element may be thrown from the assembly with substantial force if subjected to a severe shock load.

**⚠ CAUTION** Check operating speed against Maximum RPM value in Table 1.

**⚠ WARNING: Cancer -**  
[www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

For a basic installation overview, scan the QR code below:



Scan to Watch Installation Video  
 or visit our Dura-Flex product page  
 at [www.TBWoods.com](http://www.TBWoods.com)

Further component information available:

Specification sheets, 3D models  
[ecatalog.TBWoods.com](http://ecatalog.TBWoods.com)

Coupling Selection Program  
[www.TBWoods.com/Select](http://www.TBWoods.com/Select)

## Installation / Alignment


### Installation / Alignment Tools

- Hex key set
- Socket set
- Torque wrench
- Straight-edge
- Caliper
- Feeler gauge set

1. Inspect all coupling components and remove any protective coatings, lubricants, paint or rust from bores, mating surfaces and fasteners. Remove any existing burrs, etc. from the shafts.
2. Slide one hub onto each shaft using keys where required. (When using QD or Taper-Lock hubs, follow the instructions furnished with the Sure-Grip or Taper-Lock bushings.)
3. When high speed rings are to be used for spacer couplings, loosely install one ring on each half element.


4. Hold one half element on the hubs to determine the appropriate hub spacing. If using spacer elements with high speed rings, hold both half elements on hubs to make sure that the hubs do not interfere with the rings. The hub may be installed with the hub extension facing in or out. Make sure that the shaft extends into the hubs at least .8 times the shaft diameter.
5. Lightly fasten hubs to shafts to prevent them from moving during alignment.

### Angular Alignment



6. Angular Alignment: Without rotating the coupling, run a caliper around the hub and set the caliper to the widest point. Find the narrowest point with the caliper and feeler gauges. Reposition equipment until this value is as small as possible; reference Table 2 for maximum value/degree.

### Parallel Alignment



7. Parallel Alignment: Using the misalignment value from the previous step, look up the maximum allowable parallel misalignment using Table 2 and Figure 1. Without rotating the shafts, run a straight-edge around the hub and find the maximum offset with feeler gauges. If necessary, realign the shafts. Recheck parallel alignment.

8. Tighten motor and driven equipment fasteners to manufacturer specifications; recheck parallel and angular alignment.
9. When parallel and angular alignment values are within service ratings, verify that all set screws, cap screws and other fasteners are tightened to values in Table 1. Recheck parallel and angular alignment after tightening.

10. Install coupling guard per applicable safety regulations.
11. Periodically check alignment, as settling will often change equipment position.

**Table 1 - Maximum RPM and Fastener Torque Values**


Coupling Size	Maximum RPM		Element & Ring Cap Screws				BTS Hubs Set Screws			
			Imperial Elements		Metric Elements**		Imperial Hubs		Metric Hubs**	
	Standard	Spacer* (HS Rings)	Screw Size	ft-lb	Screw Size	Nm	Screw Size	ft-lb	Scw Size	Nm
WE2/WES2	<b>7500</b>	<b>7500</b>	1/4-20	17	M6-1	23	1/4-20	7	M6-1	6
WE3/WES3							5/16-18	14	M8-1.25	19
WE4/WES4										
WE5/WES5										
WE10/WES10							<b>6600</b>	<b>4800(6600)</b>	3/8-16	30
WE20/WES20	5/8-11	100	M10-1.5	32						
WE30/WES30										
WE40/WES40										
WE50/WES50										
WE60/WES60	<b>3800</b>	<b>2800(3800)</b>	1/2-13	75	M12-1.75	100	3/4-10	167	M12-1.75	54
WE70/WES70										
WE80/WES80										

\*Maximum spacer element RPM = Maximum standard element RPM if using high speed rings. HS rings come standard with sizes 2-10 and are available as an option for sizes 20-80.


\*\*Metric elements and hubs use metric hardware and are denoted by "M" in the part number, e.g. WE2M, WES2M, WE2HM28MM.

**Table 2 - Angular Inch Gap**

Hub Size		Degrees			
		1°	2°	3°	4°
WE2	in	0.03	0.07	0.10	0.13
	mm	0.8	1.7	2.5	3.3
WE3	in	0.04	0.08	0.12	0.16
	mm	1.0	2.1	3.1	4.1
WE4	in	0.05	0.09	0.14	0.18
	mm	1.1	2.3	3.5	4.6
WE5	in	0.06	0.11	0.16	0.22
	mm	1.4	2.8	4.2	5.5
WE10	in	0.06	0.13	0.19	0.22
	mm	1.6	3.2	4.9	5.5
WE20	in	0.08	0.16	0.23	
	mm	2.0	4.0	5.9	
WE30	in	0.10	0.19	0.28	
	mm	2.4	4.8	7.2	
WE40	in	0.12	0.23	0.35	
	mm	2.9	5.9	8.8	
WE50	in	0.14	0.28	0.43	
	mm	3.6	7.2	10.8	
WE60	in	0.15	0.31		
	mm	3.9	7.7		
WE70	in	0.16	0.32		
	mm	4.1	8.2		
WE80	in	0.20	0.39		
	mm	5.0	10.0		



**Figure 1 - Parallel Gap**



## TB Wood's Facilities

### North America

#### USA

440 North Fifth Avenue  
Chambersburg, PA 17201 - USA  
888-829-6637 • 717-264-7161  
*Belted Drives and Elastomeric Couplings*

**Customer Service**  
1-888-829-6637

**Application Support**  
1-888-829-6637

2000 Clovis Barker Road  
San Marcos, TX 78666 - USA  
1-888-449-9439  
*General Purpose Disc Couplings*

**Customer Service**  
1-888-449-9439

4970 Joule St  
Reno, NV 89502 - USA  
775-857-1800

#### Canada

12759 149 Street NW  
Edmonton, AB T5L 4M9 - Canada  
1-800-829-6631

1070 Mid Way Blvd  
Units 11-14  
Mississauga, ON L5T 1T4 - Canada  
1-800-829-6631

1073 Rue Bégin  
Saint-Laurent, QC H4R 1V8 - Canada  
+1 514-332-4812

#### Mexico

Comisión Federal de Electricidad 850,  
Industrial San Luis,  
San Luis, S.L.P., 78395 - Mexico  
+52 444 137 1500

#### Europe

Merchant Drive, Hertford  
Hertfordshire SG13 7BL - England  
+44(0)1992 501900  
*Elastomeric Couplings*

## The Brands of Altra Motion

### Couplings

**Ameridrives**  
[www.ameridrives.com](http://www.ameridrives.com)

**Bibby Turboflex**  
[www.bibbyturboflex.com](http://www.bibbyturboflex.com)

**Guardian Couplings**  
[www.guardiancouplings.com](http://www.guardiancouplings.com)

**Huco**  
[www.huco.com](http://www.huco.com)

**Lamiflex Couplings**  
[www.lamiflexcouplings.com](http://www.lamiflexcouplings.com)

**Stromag**  
[www.stromag.com](http://www.stromag.com)

**TB Wood's**  
[www.tbwoods.com](http://www.tbwoods.com)

### Linear Systems

**Thomson**  
[www.thomsonlinear.com](http://www.thomsonlinear.com)

### Geared Cam Limit Switches

**Stromag**  
[www.stromag.com](http://www.stromag.com)

### Engineered Bearing Assemblies

**Kilian**  
[www.kilianbearings.com](http://www.kilianbearings.com)

### Electric Clutches & Brakes

**Matrix**  
[www.matrix-international.com](http://www.matrix-international.com)

**Stromag**  
[www.stromag.com](http://www.stromag.com)

**Warner Electric**  
[www.warnerelectric.com](http://www.warnerelectric.com)

### Belted Drives

**TB Wood's**  
[www.tbwoods.com](http://www.tbwoods.com)

### Heavy Duty Clutches & Brakes

**Twiflex**  
[www.twiflex.com](http://www.twiflex.com)

**Stromag**  
[www.stromag.com](http://www.stromag.com)

**Svendborg Brakes**  
[www.svendborg-brakes.com](http://www.svendborg-brakes.com)

**Wichita Clutch**  
[www.wichitaclutch.com](http://www.wichitaclutch.com)

### Gearing & Specialty Components

**Bauer Gear Motor**  
[www.bauergears.com](http://www.bauergears.com)

**Boston Gear**  
[www.bostongear.com](http://www.bostongear.com)

**Delevan**  
[www.delevan.com](http://www.delevan.com)

**Delroyd Worm Gear**  
[www.delroyd.com](http://www.delroyd.com)

**Nuttall Gear**  
[www.nuttallgear.com](http://www.nuttallgear.com)

### Engine Braking Systems

**Jacobs Vehicle Systems**  
[www.jacobsvehiclesystems.com](http://www.jacobsvehiclesystems.com)

### Precision Motors & Automation

**Kollmorgen**  
[www.kollmorgen.com](http://www.kollmorgen.com)

### Miniature Motors

**Portescap**  
[www.portescap.com](http://www.portescap.com)

### Overrunning Clutches

**Formsprag Clutch**  
[www.formsprag.com](http://www.formsprag.com)

**Marland Clutch**  
[www.marland.com](http://www.marland.com)

**Stieber**  
[www.stieberclutch.com](http://www.stieberclutch.com)

Neither the accuracy nor completeness of the information contained in this publication is guaranteed by the company and may be subject to change in its sole discretion. The operating and performance characteristics of these products may vary depending on the application, installation, operating conditions and environmental factors. The company's terms and conditions of sale can be viewed at <http://www.altramotion.com/terms-and-conditions/sales-terms-and-conditions>. These terms and conditions apply to any person who may buy, acquire or use a product referred to herein, including any person who buys from a licensed distributor of these branded products.

©2022 by TB Wood's LLC. All rights reserved. All trademarks in this publication are the sole and exclusive property of TB Wood's LLC or one of its affiliated companies.



[www.tbwoods.com](http://www.tbwoods.com)

440 North Fifth Avenue  
Chambersburg, PA 17201 - USA  
888-829-6637 • 717-264-7161